

MS-20

Item ref: 153.320UK

20W Mini Strobe

User Manual



Caution: Please read this manual carefully before operating
Damage caused by misuse is not covered by the warranty

1. Do not open. No user serviceable parts inside - only lamp may be replaced
2. Do not aim directly at audiences' line of sight – may cause visual impairment
3. Ensure that the mains lead is in good condition and not liable to damage
4. Do not operate in areas where visual distraction may cause a hazard
5. Do not block cooling vents and keep away from heat sources
6. Be aware that strobe lights may be dangerous for epilepsy sufferers

Operation

Aim the MS-20 toward the area to be illuminated and away from direct eyesight.
Connect to the mains supply, ensuring the correct voltage.
Turn the rear rotary control to adjust to the required flash frequency.
Disconnect from the mains when not in use.

Specifications

Power supply	230Vac, 50Hz
Flash rate per second	0 - 10
Replacement lamp	153.350UK
Dimensions	55 x 98 x 137mm
Weight	500g



Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

*Errors and omissions excepted.
Copyright© 2014. AVSL Group Ltd.*