

FSS Series

Portable Floor Standing Pull-up Projector Screens

User Manual


Both quick and easy to move to your desired location and set up, these portable floor standing screens provide a professional solution for both home and business applications. An ingenious gas spring support system means you simply open the case then lift the screen out to your desired height and it's ready to use. A rugged metal housing and carry handle makes storage and transportation a breeze. Ideal for home entertainment, office meetings, education, hospitality and more.

Features:

- Easy to set up, simply twist out the feet, open the safety catches and lid, then pull up to your desired height and it's ready to go!
- Freestanding stable design for use indoors or outdoors.
- Gas spring support system allows easy adjustment to any height.
- Rugged metal housing with carry handle for easy transportation.
- Ideal for home entertainment, office meetings, education, hospitality and more.

Installation:

- 1. Position the unit on a stable, level surface ensuring it's away from excessive heat sources and walkways where it could get knocked over.
- 2. Carefully lift each end of the unit in turn and rotate the stabilizer feet (1) underneath by 90°.
- 3. Unlock the safety catches (2) on either end of the casing and open the lid.
- 4. Hold the lifting handle (3) in one hand and pull the screen firmly upwards until it reaches the desired height.
- 5. Owing to the gas spring support system on the back of the screen, it will remain safely in position.
- 6. Once finished carefully push downwards on the top of the screen until it's completely closed.
- 7. Ensure the lifting handle (3) is folded away from you before closing the lid and locking the catches (2).
- 8. Finally close the stabilizer feet (1) underneath and the unit is packed away and ready for transporting to your next location.
- 9. **Warning:** always ensure the safety catches (2) are secure before attempting to carry the unit with the carry handle (4).





Maintenance:

Maintenance and service of the unit should not be required throughout the duty life of the product. We recommend dusting on a regular basis using a dry microfibre cloth. To remove any stains on the screen surface, use a slightly damp microfibre cloth with max. 5% soap solution. Always ensure the surface is completely dry before closing the screen.

Warning:

- Do not use this screen if you find that it is damaged in any way.
- Do not attempt to repair this unit or take it apart under any circumstances, as this will invalidate your warranty.