



True Wireless Earphones and Wireless Charging Case

Ear Shots II

Item ref: 100.577UK

User Manual

Introducing the next generation of Ear Shots; taking your wireless listening experience to a new level. An improved, compact design offers a more secure fit, intuitive touch controls and true wireless technology, so you can control your music with ease without the hassle of tangling wires. These lightweight earphones feature dynamic drivers and Bluetooth 5.0 for seamless connection to smart devices. An inbuilt microphone and hands-free function allow for more freedom when answering calls. Quickly charge your earphones with the upgraded, wireless charging case. Simply place the case on a wireless charging pad to charge, providing up to 10 hours additional play time so there's nothing to hold you back.

Features

- Improved design that's smaller in size but greater in performance
- Intuitive touch controls handle your music with ease
- Wireless charging case provides up to 10 hours additional play time
- Dynamic drivers that deliver a deep immersive sound experience
- Bluetooth 5.0 connectivity for optimum transmission speed
- Built-in microphone for hands-free calls
- iOS and Android compatible

In the Box

- 2pcs True wireless earbuds
- Wireless charging case
- USB charging cable
- User guide

Technical Specifications

Speaker Driver	10mmØ dynamic	
Frequency Response	20Hz -20kHz	
Sensitivity	Earphones: ≥98dB, Microphone:-42dB	
Impedance	32 Ohms	
Power: Battery	Earphones: 2x internal 28mAh, Charging case: 300mAh	
Battery Life (hours)	Earphones: 2.5 hours max, Charging case: Up to 10 additional hours playback	
Standby Time	120 hours (approx.)	
Charge Time	Earphones: 45 mins (approx), Charging case: 1.5 hours (approx)	
Bluetooth Version	V5.0 (Airoha)	
Bluetooth Range	Up to 10m (clear line of sight)	
Dimensions	Earphones: 46.8 x 18mm, Charging case: 60 x 47mm	
Weight:	Earphones: 2 x 5.9q, Charging case: 34q (including headphones)	

Overview



Before first use

Even though your Ear Shots II will come with some battery charge, it's advisable to fully charge them before first use. Either connect the charging case and earbuds to a suitable USB power source using the lead provided or place on a wireless charging plate and leave for around 1.5 hours to ensure they are ready for use. When charging, the charging case LED will glow orange and when fully charged it will go out.

www.avsl.com 100.577UK




Pairing in True Wireless mode

The Ear Shots II are fitted with an intelligent chipset that allows instant pairing to your smart device. To enter pairing mode simply open the lid of the charging case and the LED indicator on the case will glow green to indicate it's in pairing mode. Open the Bluetooth device list on your phone or tablet and search for the pairing name "AV:LINK EAR SHOTS II" and select. If asked for a pairing code, enter "0000", your device should then connect, and you are ready to begin enjoying the true wireless sound experience of Ear Shots II. Once paired you can reconnect or disconnect to your device by simply opening and closing the lid on the charging case. Remove either one earbud for mono and hands-free use or both earbuds for the amazing stereo true wireless sound experience of Ear Shots II.

MF Touch Controls

The Ear Shots II are fitted with touch sensitive multi-function (MF) control buttons which can be programmed for your chosen control function. Enter the Bluetooth menu and press the (i) button next to the Earshots II control bar to enter the control menu. Next tap on the Left and Right control bars and choose between Siri/Voice assistant in Android (default), Play/Pause, Next Track, Previous Track or Off for no function. It is only possible to adjust the settings for the double tap function. Single taps on either earbud bring no response and three taps on either earbud will move to the next or previous track accordingly. These settings are pre-programmed in the earphone settings and cannot be changed. Note: if you are using an Android device only the default settings can be used and the menus below are only applicable for iOS devices.







Automatic Ear Detection

The Ear Shots II are also fitted with sensors on the earbuds to allow your smart device to know when they are placed or removed from your ears. This function is turned on as default but can be disabled using the toggle switch in the middle image above. When listening to music if you remove one of the earbuds from your ears the current track will pause, when you replace the earbud in your ear it will continue to play. To turn the earbuds off whilst they are connected to your device, simply remove them from your ears and return to the correct ports in the charging case. To turn the earbuds on again, simply remove them from the charging case and they will switch on and automatically pair with the last connected device, providing it's within range and Bluetooth is turned on.

Hands-free operation

When you receive a phone call during audio playback, a ringtone can be heard in the earbuds. To accept the call, press the MF touch button on either earbud twice. When you have completed the call, hang up by pressing the MF touch button on either earbud twice again.

Charging the earbuds and case

To charge the earbuds, carefully place them in the corresponding magnetic ports of the charging case and close the lid. When charging is complete, the case will automatically end the charging process. It usually takes around 45 mins to fully charge the earbuds from 'flat'. The charging case is a compact, magnetic carry case and power bank, with capacity to fully recharge the earbuds up to 4 times. To charge the charging case, connect it to a compatible USB power socket using the charging cable provided or alternatively place it on a compatible wireless charging plate. When charging, the LED indicator on the front of the charging case will glow orange and when fully charged, it will go out.

Performing a factory reset

To perform a factory reset of the earbuds and charging case open the lid with the earbuds in the case, then press and hold the charging button on the back of the case for around 10 seconds until a beep is heard and the case and earbuds glow blue.

FAQ

- Q) The Ear Shots II will not pair with my device. A) Check that the earphones are in pairing mode; Bluetooth is enabled on your device; and the device is set as 'discoverable'.
- **Q)** The Ear Shots II disconnect with my device within the stated 10m transmission distance. **A)** The maximum transmission distance stated is dependent on a clear line of sight between the earphones and your device. If there are large metallic objects or other devices transmitting radio or wireless signals in the vicinity, they may impact on the reception of the earphones.
- **Q)** The Ear Shots II won't reconnect with my device. **A)** On occasion, your Bluetooth device or the earphones may enter a locked state and need resetting. To do this, find the earphones in your device list and select "forget this device". Then, follow the instructions for "**Performing a factory reset"** above.
- **Q)** The charging case won't charge on my wireless charging pad. **A)** Some wireless charging pads are designed for fast charge devices and may not be compatible with the case. Ensure the pad you are using is Qi compatible and that the charging case is placed squarely on the centre of the pad.

Safety Disclaimer



Do not attempt to service this product yourself as opening or removing covers may result in fire, electric shock or equipment damage and will also invalidate the warranty. This product is only designed for indoor use and must be kept away from water and high humidity along with high temperatures and direct sunlight. Prolonged listening at high volumes can cause hearing damage. Keep away from young children as small parts can be a choking hazard.



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life.

The goods must be disposed of according to your local council guidelines.