


18 Inch High Velocity Floor Fan

Order ref: 450.009UK

User Manual



A stylish, high velocity floor fan with 3 speed settings and tilt control. Ideal for home and work, it is powerful and sturdy, and offers an attractive chrome finish. The steel mesh guard is easy to detach and replace, allowing for easy cleaning of the interior and fan blades as required.

Specification:


Cable length	1.65m
Power output	110W
Blade diameter	440mm
Mains power	220-240V
Dimensions	535 x 555 x 195mm
Weight	5.2kg

Features:

- High velocity 110W motor
- 3 speed settings
- Attractive chrome finish
- Head is adjustable through 120°

Assembly diagram:

1. Front grille
2. Fan blade
3. Fan motor
4. Rear grille
5. Floor stand
6. Rear fan controls



Speed controls (at the back)



Operation:

1. The fan will arrive pre-assembled, but before use take time to inspect the unit and ensure it isn't damaged in any way.
2. Set the fan on a dry, level and secure surface. It is designed for floor use only and must never be hung or balanced anywhere where it could fall and cause injury or damage to the fan.
3. Connect the fan to the mains supply using the 1.65 m power lead and plug.
4. To operate the fan, press button 1, 2 or 3 to select low, medium or high speed.
5. To stop the fan, press button 0.
6. To adjust the tilt of the fan, simply move the head unit up or down, selecting the desired gradient.

Cleaning the fan blades:

To clean the fan blades and keep them free from dust and dirt, disconnect the fan from the mains supply and remove the front grille. Clean the blades and grille using a soft, damp cloth, rinsed in soapy water. Take care to not press too hard or allow moisture to get into the fan motor.

Warnings:

- For reasons of electrical safety, this device must never be immersed in water, exposed to damp conditions or excessive force.
- Do not use this device if you find that it is damaged in any way.
- Do not attempt to repair this device or take apart under any circumstances, as this will invalidate your warranty.
- Never cover the fan or place anything on the grilles, as this may result in overheating or fire.
- Never allow foreign objects to be pushed into the motor, or fan blades as this may result in fire, injury or damage to the fan.
- Due to the high output of this unit, never leave switched on for long periods unattended where it may cause light items such as curtains or bedding to be moved around.



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

*Errors and omissions excepted.
Copyright© 2018. AVSL Group Ltd.*