# @ mercury



## **Wireless Door Chime with Light**

Order ref: 350.297UK

User Manual

A portable battery-operated wireless doorbell with visual indication and 16 melodies. Easy to setup and use, the internal chime unit can be wall mounted or free-standing. When activated a light flashes on the internal unit making it ideal for noisy environments or the hard of hearing.

#### Specification:

Battery: receiver	4.5Vdc (3 x AA)
Battery: transmitter	12Vdc (23A)
Frequency	433.92MHz (±150kHz)
Range	100m (open air)
Dimensions	Receiver: 118 x 39 x 85mm; Transmitter: 88 x 20 x 36.5mm
Weight	Receiver: 103g; Transmitter: 25g

#### Features:

- Simple wire-free installation
- Freestanding or wall mountable
- Choice of 16 melodies
- Digital coded signal to prevent outside interference
- Wireless range of up to 100m
- Transmitter battery (12V 23A) supplied, receiver requires 3 x AA size batteries (not supplied)

#### Transmitter Installation:

- 1. Remove the front cover of the transmitter and insert the 12V battery supplied, observing the polarity indicators within the battery compartment.
- Mount the unit on the doorframe or window frame using the adhesive pad provided. Please ensure the mounting surface is clean and free from grease before installation.

#### **Receiver Installation:**

- Insert 3x AA batteries (not supplied) into the receiver unit observing the polarity indicators within the battery compartment and locate within 100m range of the door press transmitter. Try to ensure there is a clear line of sight between the units if possible and that there are no radio receivers or wireless devices in the direct location of the unit to avoid interference.
- Press the button on the transmitter to test that both units are connected properly and that there are no issues with signal or interference.
- 3. Press the button on the side of the receiver unit repeatedly to select one of the 16 melodies available.
- 4. If the receiver fails to sound when the transmitter is depressed at any time, please replace the batteries.
- If required the channels can be changed by fitting the supplied jumpers on the transmitter and setting the dip switches on the receiver unit accordingly, thus allowing the use of multiple receivers against single transmitters.

### Warning:

- · For reasons of electrical safety, this device must never be immersed in water, exposed to damp conditions or excessive force.
- Do not use this device if you find that it is damaged in any way.
- Do not attempt to repair this device or take apart under any circumstances, as this will invalidate your warranty.



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

Hereby, AVSL Group Ltd. declares that the radio equipment type: 350.297UK complies with Directive 2014/53/EU. The full text of the EU declaration of conformity for 350.297UK is available at the following internet address: <a href="http://www.avsl.com/assets/exportdoc/3/5/350297UK%20CE.pdf">http://www.avsl.com/assets/exportdoc/3/5/350297UK%20CE.pdf</a>

#### Errors and omissions excepted.

Copyright© 2021 AVSL Group Ltd, Unit 2 Bridgewater Park, Taylor Road, Trafford Park, Manchester. M41 7JQ. AVSL (Europe) Ltd, Unit 3D North Point House, North Point Bus. Park, New Mallow Road, Cork, Ireland.